
HOME E ANCE

ASSEMBLY INSTRUCTIONS

Accent chair

Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to spliting or cracking the wood.



Care Instruction for Microfiber Furniture:

In order to maintain the original appearance of your Microfiber furniture, please follow below simple care proceures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets.

 Sunlight and or exposure to heating and air conditioning outlets will fade/damage Microfiber.
- Vacuum or wipe with a soft cloth to remove dust.
- Hardware may loosen over time. Periodically check to make sure all connection are tight. Re-tighten if necessary.



For item use on wooden floor,hard surfaces or carpets,it is recommended to install protective pads under all legs and supports to avoid/prevent from damages/ scratches and discoloration.