
Assembly Instruction

ITEM NO.:


8378BLK-4/BRW-4/GRY-4/WHT-4 OTTOMAN

NOTE:Do not use power tools for assembly.Power tools increase the risk of over tightening which lead to splitting or cracking the wood.


COMPONENT LIST

NO.	DRAWING	QTY	DESCRIPTION
A		4	METAL LEG
B		8	WASHER
C		1	ALLEN KEY
D		8	BOLT
I		1	OTTOMAN


Legs and hardware are stored at the bottom of the 3 seater and chaise, please take out for assembly.



Step 1 Align the legs to the pre-drilled holes at the bottom of the units, insert bolts and washers then tighten with Allen Key.



Step 2



Care instruction for PU furniture.

In order to maintain the original appearance of your PU furniture,
please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and/orexposure to heating and air conditioning outlets will fade/damage PU. Do not place your PU surface furniture too close to windows,radiators,or vents,and be sure to use windows,radiators,or vents.
- Vacuum or wipe with a cloth regularly to remove dust.
- Clean PU surface furniture with professional cleanser.

⚠ For items use on wooden floor,hard surfaces or carpets,it is recommended to install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.