



ASSEMBLY INSTRUCTION
3588-30 LIFT TOP COCKTAIL TABLE

PARTS LIST:



1: TABLE TOP 1pc

2: BOTTOM SHELF 1pc

3: LEG 4pcs


HARDWARE LIST

A	B	C	D	E	F
					
Ø5/16"×2" L	5mm	CASTER WITH LOCK	CASTER	ALLEN WRENCH	Ø8*1-1/4"
8PCS	1PC	2PCS	2PCS	1PC	4PCS


STEP#1

LOCK

UNLOCK




STEP#2




ASSEMBLY INSTRUCTION

3588-30 LIFT TOP COCKTAIL TABLE


STEP 3



STEP 4



COMPLETED



Please make sure the lower panel is assembled on the correct side with weight support to prevent tilting.

CAUTION!

Do not allow children to play on the mechanized furniture or operate the mechanism. Top surfaces fold down on closing, so that a child could possibly be injured. Always leave furniture in the closed position when unattended. To prevent the table from tipping over, do not place more than 30 pounds on the top when in the open position. **KEEP HANDS CLEAR OF MECHANISM.**



For items use on wooden floor, hard surfaces or carpets, it is recommended to install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.