




## Assembly Instruction **CORNER SEAT** ITEM NO.: 8318-CR

**NOTE: Do not use power tools for assembly. Power tools increase the risk of over tightening which leads to splitting or cracking the wood.**


### COMPONENT LIST (CHAIR)

NO.	DRAWING	QTY	DESCRIPTION
<b>A</b>		<b>1</b>	<b>CORNER SEAT</b>


### HARDWARE LIST

NO.	DRAWING	QTY	DESCRIPTION
<b>1</b>		<b>1</b>	<b>EXTENSION CORD</b>



**STEP#1**



**STEP#2**







**REMARK:**  
Y-Cable MUST be used when combination include two electrical function reclining chair.



**REMARK:**  
Y-Cable will NOT be used when combination include ONLY one electrical function reclining chair.

**STEP#3**



**CARE INSTRUCTION FOR TOP GRAIN LEATHER & FABRIC:**

In order to maintain the original appearance of your top grain leather & fabric furniture, please follow below simple care procedure

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Exposure to sunlight or heating and air conditioning outlets will fade/damage leather and fabric.
- Wipe gently with a damp soft cloth to remove dust, dirt and any grime build up.
- Wipe leather and fabric with professional cleanser.