








# Assembly Instruction

Power Double Reclining  
Sofa with USB Ports




ITEM NO.: 8479BEG-3PW

Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to spliting or cracking the wood.


## Component list

No	Drawing	Qty	Description
<b>A</b>		<b>1</b>	<b>Seat</b>
<b>B</b>		<b>2</b>	<b>LSF/RSF Backrest</b>
<b>C</b>		<b>1</b>	<b>Middle Backrest</b>
<b>D</b>		<b>1</b>	<b>Adaptor</b>
<b>E</b>		<b>1</b>	<b>Plug</b>


THE PARTS ARE LOCATED INSIDE THE BOX AS BELOW:



## Step #1




## Step #2



### Step #3

Assembly completed.



## Care Instruction for Chenille Furniture:

In order to maintain the original appearance of your chenille fabric, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and/or exposure to heating and air conditioning outlets will fade/damage chenille. Do not place your upholstered furniture too close to windows, radiators, or vents, and be sure to use windows, radiators, or vents.
- Vacuum or wipe with a soft cloth to remove dust.
- Hardware may loosen over time. Periodically check to make sure all connections are tight. Re-tighten if necessary.



For items use on wooden floor, hard surfaces or carpets, it is recommended to Install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.