


# ASSEMBLY INSTRUCTION

ITEM NO: 9277VR-2A ARMLESS 2- SEATER

LEGS AND HARDWARE ARE STORED IN THE BOTTOM OF THE SEAT, PLEASE TAKE OUT FOR ASSEMBLY.

| NO. | PARTS LIST  | QTY | DESCRIPTION       |
|-----|---|-----|-------------------|
| A   |  | 1   | ARMLESS 2- SEATER |


| NO. | HARDWARE LIST   | QTY | DESCRIPTION |
|-----|---|-----|-------------|
| B   | <br>80*80*50mm  | 4   | WOODEN LEGS |
| C   | <br>M8*60mm     | 4   | BOLT        |
| D   | <br>M5*100*38mm | 1   | ALLEN KEY   |

# ASSEMBLY INSTRUCTION

ITEM NO: 9277VR-2A ARMLESS 2- SEATER


## STEP 1

PARTS INSIDE




## STEP 2

9277VR-2A



9277VR-2L      9277VR-CR      9277VR-2A      9277VR-RC



### CARE INSTRUCTION FOR FABRIC FURNITURE

In order to maintain the original appearance of your fabric furniture, please follow below simple care procedures.

°Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Exposure to sunlight or heating and air conditioning outlets will fade/damage fabric.

°Wipe gently with a damp soft cloth to remove dust, dirt and any grime build up.