

ASSEMBLING INSTRUCTIONS

ITEM NO: 9506-F1S
PUSH BACK RECLINING CHAIR




Legs and hardware are stored in the bottom of the seat, please take them out for assembly.
Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.

PART	DRAWING	DESCRIPTION	QTY
A		Seat	1 PC
B		Backrest	1 PC
C		Right Wing	1 PC
D		Left Wing	1 PC


ASSEMBLING INSTRUCTIONS

ITEM NO: 9506-F1S
PUSH BACK RECLINING CHAIR

STEP 1:





STEP 2:



ASSEMBLING INSTRUCTIONS

ITEM NO: 9506-F1S
PUSH BACK RECLINING CHAIR

COMPLETED



Care Instruction for Textured Fabric Furniture:

In order to maintain the original appearance of your Textured Fabric furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets.
- Sunlight and or exposure to heating and air conditioning outlets will fade / damage Textured Fabric.
- Vacuum or wipe with a soft cloth to remove dust.
- Hardware may loosen over time. Periodically check to make sure all connection are tight, Re-tighten if necessary



For item use on wooden floor, hard surfaces or carpets, it is recommended to install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.