









Assembly Instruction

ITEM NO.: 9426-3

DOUBLE RECLINING SOFA WITH DROP-DOWN CUP HOLDERS

NOTE: Do not use power tools for assembly. Power tools increase the risk of over tightening which leads to splitting or cracking the wood.

COMPONENT LIST (SOFA)

NO.	DRAWING	QTY	DESCRIPTION
A		1	SEAT
B		1	LSF BACK REST
C		1	MIDDLE BACK REST
D		1	RSF BACK REST
E		1	LSF EAR
F		1	RSF EAR

STEP# 1


Attach LSF Back Rest(B) and RSF Back Rest(D) to the Seat (A).

STEP# 2


Attach Middle Back Rest (C) to the seat(A) .


STEP# 3

Attach the LSF Ear (E) to LSF Back Rest(B) and RSF Ear(F) to the RSF Back Rest(D).



STEP#4 Completed





Care Instruction for Polished Microfiber Furniture.

In order to maintain the original appearance of your Polished Microfiber furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and/or exposure to heating and air conditioning outlets will fade/damage polished microfiber.
- Do not place your upholstered furniture too close to windows, radiators, or vents and be sure to use window, radiators, or vents.
- Vacuum or wipe with a soft brush to remove dust.



For items used on wooden floor, hard surfaces or carpets, it is recommended to install protective pads under all legs supports to avoid/prevent from damages/scratches discoloration.