







Assembly Instruction

ITEM NO:8216DG / SD-1

CHAIR


NOTE: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.

COMPONENT LIST


NO.	DRAWING	QTY	DESCRIPTION
A		1	BACK CUSHION
B		1	SEAT CUSHION
C		1	BACK REST
D		1	SEAT FRAME
EL		1	LEFT ARM FRAME
ER		1	RIGHT ARM FRAME
F		4	PLASTIC LEG
G		4	PLASTIC WASHER
H		2	FLAT WASHER
I		1	ALLEN KEY
J		2	BOLT

Please follow the drawings below to assemble the item.
Plastic legs are stored in the box, please take out for assembly.


Step 1.




Step 2.




Step 3.




Step 4.




Step 5.



Step 6.



Completed.



CARE INSTRUCTION FOR 100% POLYESTER FURNITURE:

In order to maintain the original appearance of your 100% polyester furniture, please follow below care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and / or exposure to heating and air conditioning outlets will fade/damage 100% polyester. Do not place your upholstered furniture too close to windows, radiators, or vents, and be sure to use window treatments to block the sun's rays.
- Wipe with a soft brush to remove dust.
- Wipe 100% polyester with professional cleanser.



For items use on wooden floor, hard surfaces or carpets, it is recommended to Install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.